

ENGLISH GARDEN

ASSEMBLY INSTRUCTIONS

#221C,B English Garden Arm Chair

Counter Height/Bar Height



Tools Required

- Hammer
- #2 Square Head Bit
- Power Drill
- 7/16" Socket or 7/16 wrench

Included Hardware

A		2 2" Screws
B		4 2½" Screws

Instructions:

1. Follow instructions on the opposite side to assemble the chair.
2. Fasten the arm to the back of the chair using 1 (A) 2" Screw. (Illustration 1)
3. Holding the leg of the arm flush with the seat (Illustration 2), fasten with 2 (B) 2½" Screws using the pilot holes under the seat. (Illustration 3)
4. Repeat on the other side.

