BALCONY & PUB
ASSEMBLY INSTRUCTIONS

# #322C, B Balcony Settee

#322C Counter Height | #322B Bar Height



## Tools Required

- Hammer
- #2 Square Head Bit
- Power Drill
- 7/16” Socket

## Included Hardware

| | | |
|---|---|---|
| **A** |  | 12 1½” Screws |

## Instructions:

1. Use instructions from #321C, B Balcony Chair to assemble chairs.
2. With the two chairs setting upright, line up the table with the arms. Keep point flush with the round part of the arm rest. Fasten using 2 (A) 1½” Screws. (Illustration 1)
3. Fasten the back of the table to the arms using 2 (A) 1½” Screws. (Illustration 2)
4. Then fasten the bottom shelf using 8 (A) 1½” Screws. (Illustration 3)



Illustration 1




Illustration 2




Illustration 3