ENGLISH GARDEN
ASSEMBLY INSTRUCTIONS

#940 English Garden Bench Poly



Tools Required

- Hammer
- #2 Square Head Bit
- #2 Square Drive 6" Extension
- Power Drill
- 7/16” Socket or 7/16 wrench

Included Hardware

A		6	¼” x 3” Lag Bolt
B		5	1½” Screws
C		12	2” Screws
D		4	2½” Screws

Instructions:

1. Unpack items from box(es). Be sure to match any numbers & letters that you may find on the pieces.
2. With a side arm/leg combo upright, using the bottom pre-drilled hole fasten the back brace to the arm/leg combo with 1 (A) 1/4" x 3" lag. (Illustration 2) Repeat on the other side.
3. Using the center pre-drilled hole on the arm/leg combo, fasten the bottom of the back using 1 (A) 1/4” x 3” lag. Then fasten the top of the back to the arm/leg combo using 1 (A) 1/4” x 3” lag. (Illustration 3). Repeat on the other side.
4. Then attach the front seat brace, begin by using 2 (D) 2 ½" screws and fast the angle brace to the leg. (Illustration 4) Repeat on the other side.
5. The turn the bench upside down so that it is resting on the arms to finish fastening the brace. Using 2 (C) 2" screws fasten the brace to the leg. (Illustration 5)
6. With the bench still upside down, line the seat up with the markings and fasten using 4 (C) 2" Screws. (Illustration 6) Repeat on the other side.
7. Insert the metal brace into the notch on the center of the seat. Measure to be sure the brace falls at the same place on either side of the seat. (Illustration 7) Then attach the brace using 5 (B) 1½" Screws. (Illustration 8)















