

FANBACK SERIES
ASSEMBLY INSTRUCTIONS

#30 Child's Swing



Tools Required

- Hammer
- #2 Square Head Bit
- Power Drill
- 7/16" Socket or 7/16" Wrench

Included Hardware

A		4	1/4" x 2 1/2" Carriage Bolt
B		2	1/4" x 3" Carriage Bolt
C		8	1/4" Nut
D		2	3/8" x 4" Eye Bolt

Instructions:

1. Unpack items from box(es). Be sure to match any numbers & letters that you may find on the pieces.
2. With the seat laying on a flat surface, place the back into place. (Illustration 2)
3. Using 2 (A) 1/4" x 2 1/2" Carriage Bolts, hammer the carriage bolts into the seat to fasten into the back. (Illustration 3)
4. Turn the seat and back upside down and using a 7/16" Socket fasten 2 (C) 1/4" nuts. (Illustration 4). Repeat on the other side before tightening all nuts.
5. To attach the arms, begin by using a 1 (B) 1/4" x 3" Carriage Bolt to fasten the arm to the back. Insert the bolt and then use a 7/16" socket to fasten the (C) 1/4" nut on the inside of the back. (Illustration 5) Repeat on the other side.
6. Insert 1 (D) 3/8" x 4" Eye Bolt into the leg of the arm to attach to the seat. (Illustration 6). Use a (C) 1/4" nut on the inside of the seat. Tighten. (Illustration 7). Repeat on the other side.

